





Assistenza Tecnica After Sales Service Service Apres Vente Kundendienst Servicio Post-Venta

Otsein 

37500618 LT613

Service Manual





**Mod: 37500618 LT613 9837 (08/09/1998)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
5	Door safety device	80001407		
10	Timer/select. knob	80002090		
14	Temp.regulation knob	80002066		
15	Cam disc	92134956		
19m	Simple push button	80001928		
19o	Button with control lamp	80001969		
31	Control panel	80001993		
34	White cover	80006935		
37	Upper shelf	80001886		
44	Direction control rod	92673946		
52	Direction control rod	92134964		
55	Insulating side	92943547		
68	Plug	92137298		
70	Trolley wheel	80001795		
70a	Chassis assy with wheels	80012917		
70b	Protection	80034267		
76	Cabinet assy	80036528		
76b	Cabinet side cover	80007347		
76c	Cabinet side cover gasket	80007180		
76d	Cabinet upper cover gaske	80007826		
77	Rear panel	80034564		
79	Rear foot	92606474		
80	Front foot	92692300		
94	Filtert knob	92615285		
94a	Bolt	92415140		
95	Filter cartridge	92945468		
96	Gasket	92606391		
96a	Gasket	92607639		
97b	Filt.hous.without recycle	92132109		
101	Dispenser drawer	80002132		
114	Driving lever	80016595		



Mod: 37500618 LT613 9837 (08/09/1998)

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
118	Spring	80001183		
124	Press.fixing plate	80000342		
132	Valve hose cold water	80034770		
133	Hose clip	80034762		
134	Solenoid valve	90450750		
138	Drain hose	80034556		
138a	Drain house elbow	80001787		
141	Rubber washer	92485226		
142	Fill hose	92250869		
151	Timer	80017296		
152b	4 push buttons key board	92125806		
153	Pressure switch	80001340		
155a	White indicator light	80013006		
155a	White indicator light	80007743		
156f	Capacitor 14 MF	80001316		
157	Harness	80019078		
161	Drain/recycle pump	80033772		
164	Anti jamming filter radio	92205525		
166	Hose clip	80001126		
171	Main motor	80032139		
175	Motor variable pulley	92791466		
176	Sleeve	92475094		
201	Front flange	80035108		
202	Drum	80035124		
203	Tub	80035140		
205a	Right drum shaft assy	80000516		
205b	Left drum shaft assy	80032584		
205c	Drum shaft fixing kit	81448136		
206	Rolling shutt withou hook	80024920		
207	Rolling shutter with hook	80024912		
208	R/H spring	80010242		


**Mod: 37500618 LT613 9837 (08/09/1998)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
208a	L/H spring	80010259		
211	Bolt	80000946		
212	Asbestos washer	80000755		
215	Tub gasket	80018989		
227	Motor stay bolt	80000995		
228	Shock absorber bearing	80001647		
228a	Pulley bearing	80001639		
230	Tub gasket clip	92787316		
232	Heater holder	92675891		
242a	R/H support spring	80002306		
242b	L/H support spring	80002298		
244	Washer	80000664		
250	Damper pads	92697838		
251	Shoch absorber spring	80002322		
256	Clamp	92851302		
257	Damper slide	92863976		
259	Support	92673961		
271	Door gasket	80007818		
272	Discharge pipe	80033939		
273	Fill pipe	80001589		
274	Pressure switch air chamber	80001845		
275	5x8 hose	80024987		
281	Shock Absorder grommet	92606227		
286	Heater	80023609		
287b	Thermostat (30/90)	92216498		
288	Temperature regulator	80008394		
290	Drum pulley	80036569		
292	Drive belt	80001712		
304	Gasket	80015936		
491	Mains cable	80001530		
568	Spring for push.button	92483916		

**Mod: 37500618 LT613 9837 (08/09/1998)**

Ref.	Descrizione - Description - Beschreibung - Descripcion	Ricambio Part No. Piece E-Teil Pieza	Inizio Beginning Debut Begin Inicio	Fine Ending Fin End Fin
569	Pin for push buttons	80000557		
574	Transparent program plate	80011489		
580	Front counterweight	80001720		
582	Pulley side count.weight	80001738		
584	Drum support fixing screw	80001191		
586	Counter cover pin	92730696		
587	Counter cover stopper	92137306		
588	Siphon	92134972		
603	Self-cleaning protect.	80034655		
604	Filter door	80011828		
606	Spring for filter door	80002264		
624	Tire for tightening tub	80018666		
673	Timer knob cover	80002108		
679	Knob cover	80001910		
735	Closure ring spring	80002314		
736	Closure ring screw	80018690		
739	OR timer knob	90454182		
740	OR thermostat knob	90454349		
789	Door safety device bracket	80000466		
790	Door safety device spring	80031784		
792	Gasket support	80027261		
839	Clip	80001118		
839	Clip	80001142		
842	Tub bearing disk	80037468		
843	Flange bearing disk	80037484		
844	Disk fixing screw	80040223		
845	Gasket	80032626		
846	Washer	80036585		
999	Wiring diagram	80017882		


A12



80017882

000882

B₁



- | | | | |
|---------|----|-----------|----|
| AZZURRO | AZ | ROSA | RS |
| GRIGIO | GR | BIANCO | BL |
| ROSSO | RJ | NERO | NE |
| VIOLA | VI | VERDE | VE |
| MARRONE | MA | GIALLO | AM |
| | | ARANCIONE | NA |

80017882

000883

